



Krome color

Operation Manual

Thank you for choosing ShowUp products.

We recommend that you should practice with this operation manual for your consent in advance.

KROME is a particular coating. The smoother the surface is, the more metallic KROME looks.

1. First, clean up the surface to wipe up dusts.
2. Apply basecolor. Use black if you want the chrome feeling. Use silver if you want the aluminum feeling.
Ensure that the basecolor is completely dry. Otherwise, KROME doesn't come out completely.
3. Make sure that there are no dusts or cracks after the surface is dry to ensure KROME comes out appropriately.
4. Clean up oil contents of the surface.
5. Use a small caliber spray gun.(smaller than 1.3mm) Spray KROME with a small discharge like an atomizer.
6. After making the surface dry, repeat the procedure NO.5 two or three times if the color is still uneven. Please apply the color thin and even throughout the surface. Ensure not to apply too much color in order to appropriately bring out the KROME color.
7. **Make the KROME paint perfectly dry. (usually takes about 24 hours)**
8. Spray topcoat clear once after the surface is perfectly dry. (Add hardener to clear. Do not use thinner.)



KROME 180g



Cautions

When you handle this product, make sure to use rubber gloves and glasses to protect your skin and eyes.

In case it gets into your eyes, wash them with running water thoroughly and see a doctor.

In case it comes into contact with your skin, please wash it thoroughly until the slimy feeling is gone.

If you feel pain and something amiss, ask a doctor for instruction.

After use, make sure to close the lid firmly and leave it where it dark and cold, away from the direct sun.

Please keep it away from young children.

Signal Inc., SHOW UP Division

2-6-8 Aoshinke Mino Si Osaka, Japan 562-0024

Tel. 072-727-7123 Fax. 072-727-2678 Email. info@showup.jp

<http://www.showup.jp>