



Prop Cleaner

USER INSTRUCTION

Prop Cleaner is an abrasive surface treatment detergent that can be degreased and remove mold release agents.

It has better degreasing power than neutral detergent and prevents repelling and peeling.

It is possible to easily improve the adhesion of paint to ABS, PS, and RC body and polycarbonates.

【How to use】

1. Shake the container thoroughly.
2. Wet a sponge (melamine sponge), toothbrush, and rag with water, apply an appropriate amount of prop cleaner, and rub the coating.
3. After scrubbing, rinse well with water. When the bubbles are gone, you're done.
4. Finally, wipe it up with a clean cloth to completely remove moisture before proceeding with the painting work.



Signal Inc., SHOW UP Division, 2-6-8 Aoshinke Mino Si Osaka, Japan 562-0024 Tel. +81 72-727-7123

[Go to product page.](#)